


**INSTALLATION NOTES:**

**IT IS RECOMMENDED TO PRE DRILL HOLES WHEN ATTACHING THE TRIM AS TO AVOID SPLITTING ANY OF THE MOLDING. USE FINISH NAILS & GLUE. (RENTING A BRAD GUN IS A GOOD IDEA AND YOU WON'T NEED TO PRE-DRILL HOLES.)**

**TOTAL STACK HEIGHT: 7-9/16"**

**INSTALL WALL TO WALL:**

1. INSTALL CLEAT #1 9/16" IN FROM FACE FRAME (CUT TO SIZE.)
2. INSTALL TCM8 ON TOP OF CABINET (CUT TO SIZE).
3. INSTALL #2 CLEAT 1 1/8" IN FROM FRONT OF TCM8 (CUT TO SIZE.)
4. INSTALL VV96 TO CLEAT #2 (CUT TO SIZE.)
5. INSTALL CROWN MOLDING (VCRM8) TO TOP OF VV96 (CUT TO SIZE.)



\* SUPPLIED BY OTHERS.