

## Installation Instructions – STKMLD5


### INSTALLATION NOTES:

**IT IS RECOMMENDED TO PRE DRILL HOLES WHEN ATTACHING THE TRIM AS TO AVOID SPLITTING ANY OF THE MOLDING. USE FINISH NAILS & GLUE. (RENTING A BRAD GUN IS A GOOD IDEA AND YOU WON'T NEED TO PRE-DRILL HOLES.)**

**TOTAL STACK HEIGHT: 7-13/16"**

### INSTALL WALL TO WALL FIG: 1

1. INSTALL TF396 #1 - 1" OUT FROM FACE FRAME TO TOP OF CABINETS (CUT TO SIZE.)
2. INSTALL (CLEAT 1) 1" BACK FROM TF396 #1 (CUT TO SIZE.)
3. INSTALL TF396 #2 (CUT TO SIZE.)
4. INSTALL (CLEAT 2) (CUT TO SIZE.)
5. INSTALL TF396 #3 ON TOP OF CLEAT 2 & TF396 #2.
6. INSTALL (CLEAT 3) 7/16" BACK FROM FACE OF TF396 #3.
7. ATTACH SWVCRM8 TO CLEAT 3 (CUT TO SIZE).
8. ATTACH BOTH DE8 TO TF396 1 & 3.
9. ATTACH RPM8 TO SWVCRM8.



\* SUPPLIED BY OTHERS.