

INSTALLATION NOTES

IT IS RECOMMENDED TO PRE DRILL HOLES WHEN ATTACHING THE TRIM TO AVOID SPLITTING THE MOLDING. USE FINISH NAILS & GLUE.

TOTAL STACK HEIGHT: 4-1/2”

INSTALL WALL TO WALL

1. INSTALL CLEAT TO TOP OF CABINET - FLUSH TO FRONT OF CABINET FACE FRAME.
2. INSTALL VV96 TO FRONT OF CLEAT.
3. INSTALL SWCRM8 TO FRONT OF VV96 - TOP OF SWCRM8 PULLED UP FROM TOP OF VV96 AS NEEDED FOR FIELD CONDITIONS.

