

## Installation Instructions – STKMLD16

### INSTALLATION NOTES:

**IT IS RECOMMENDED TO PRE DRILL HOLES WHEN ATTACHING THE TRIM TO AVOID SPLITTING THE MOLDING. USE FINISH NAILS & GLUE.**

**TOTAL STACK HEIGHT: 3-5/16"**

### INSTALL WALL TO WALL

1. INSTALL LB2 ON TOP OF CABINET - PULLED 3/8" PAST FRONT OF FACE FRAME
2. INSTALL SWVCRM8 TO FRONT OF LB2 - BOTTOM OF SWCRM8 ALIGNED TO BOTTOM OF LB2.
3. INSTALL DE8 TO THE INSERT POSITION OF SWVCRM8.

