

## Installation Instructions – STKMLD14

### INSTALLATION NOTES:

**IT IS RECOMMENDED TO PRE DRILL HOLES WHEN ATTACHING THE TRIM TO AVOID SPLITTING ANY OF THE MOLDING. USE FINISH NAILS & GLUE.**

**TOTAL STACK HEIGHT: 3-3/32"**

### INSTALL WALL TO WALL

1. INSTALL TF396FH ON TOP OF CABINET - PULLED 3/4" TO BE FLUSH WITH THE FRONT OF CABINET DOOR.
2. INSTALL FIRST LB2 TO TOP OF TF396FH - FRONT OF FIRST LB2 SET BACK 3/8" FROM FRONT OF TF396FH.
3. INSTALL SECOND LB2 TO FRONT OF FIRST LB2 - PULL TOP OF SECOND LB2 25/32" UP FROM TOP OF FIRST LB2.

