

Installation Instructions – STKMLD12


INSTALLATION NOTES:

IT IS RECOMMENDED TO PRE DRILL HOLES WHEN ATTACHING THE TRIM AS TO AVOID SPLITTING ANY OF THE MOLDING. USE FINISH NAILS & GLUE. (RENTING A BRAD GUN IS A GOOD IDEA AND YOU WON'T NEED TO PRE-DRILL HOLES.)

TOTAL STACK HEIGHT: 5-3/8"

INSTALL WALL TO WALL:

1. INSTALL CLEAT 3/4" BACK FROM FACE FRAME (CUT TO SIZE.)
2. GLUE & NAIL (CAPM) TO TF396, THEN ATTACH TO TOP OF CABINETS (CUT TO SIZE.)
3. ATTACH (GREEKM) TRIM TO TOP OF TF396 (CUT TO SIZE.)
4. ATTACH CROWN MOLDING (SHKRCRM8) ON TOP OF TF396. SET CROWN FLUSH WITH GREEKM TRIM.



* SUPPLIED BY OTHERS.