

## Installation Instructions – STKMLD21

### INSTALLATION NOTES:

**IT IS RECOMMENDED TO PRE DRILL HOLES WHEN ATTACHING THE TRIM TO AVOID SPLITTING THE MOLDING. USE FINISH NAILS & GLUE.**

**TOTAL STACK HEIGHT: 4-7/16"**

### INSTALL WALL TO WALL

1. INSTALL CLEAT TO TOP OF CABINET.
2. INSTALL VFR8 TO TOP OF CABINET - FRONT OF VFR8 ALIGNED WITH BOTTOM OF TF396FH.
3. INSTALL TF396FH/VFR8 TO CLEAT.
4. INSTALL SWLCRM8 TO FRONT OF TF396FH - TOP OF SWLCRM8 PULLED UP FROM TOP OF TF396FH AS NEEDED FOR FIELD CONDITIONS.

