

Installation Instructions – STKMLD13

INSTALLATION NOTES:

IT IS RECOMMENDED TO PRE DRILL HOLES WHEN ATTACHING THE TRIM TO AVOID SPLITTING ANY OF THE MOLDING. USE FINISH NAILS & GLUE.

TOTAL STACK HEIGHT: 2-5/16"

INSTALL WALL TO WALL

1. INSTALL FIRST LB2 ON TOP OF CABINET - FLUSH TO THE FACE FRAME.
2. INSTALL SECOND LB2 TO FRONT OF FIRST LB2 - BOTTOM OF SECOND LB2 ALIGNED WITH BOTTOM OF FIRST LB2.
3. INSTALL THIRD LB2 TO FRONT OF SECOND LB2 - PULL THIRD LB2 3/4" PAST TOP OF SECOND LB2.

